



HANSABASIC

Installation and maintenance guide



4-9



10,12,
13




11-12



14-19



20



21





22



5578 0113



EN 1112, EN 1113
50 - 500 kPa
0.28 l/s (300 kPa)
max. +65°C



mpi.hansa.com/55780113

5578 0133


EN 1112, EN 1113
50 - 500 kPa
0.19 l/s (300 kPa)
max. +65°C









mpi.hansa.com/55780133


5515 0131

I (ISO 3822)
EN 1111
100 - 1000 kPa
0.16 l/s (Eco)
0.19 l/s (300 kPa)
max. +65°C












mpi.hansa.com/55150131











1 3







cleaning.hansa.com