










































NATUREL®



BFRAMEREG4

CZ Instalační návod
EN Mounting Instruction
DE Installationsanleitung
SK Inštalačný návod
FR Instructions d'installation
IT Istruzioni per l'installazione
ES Instrucciones de instalación
HU Szerelési útmutató











C



4 x H



H



D




1 x 15



2 x I




1 x J





15

I



J




E



F



G



8 x H

H

H



1 x 13








1 x 14







2 x P




4 x K








M



O




2x D




1x O




D





N




O



P





SIKO KOUPELNY a.s.
Skorkovská 1310, 198 00 Praha 9
IČ: 26065801