






N A T U R E L[®]

HOMETAB




CZ Instalační návod
EN Mounting Instruction
DE Installationsanleitung
SK Inštalačný návod
FR Instructions d'installation
IT Istruzioni per l'installazione
ES Instrucciones de instalación
HU Szerelési útmutató



2 x **1**

2 x **2**



1 x **3**




1 x **4**

8 x **5**



1 x **6**




ø ca. / aprox.
5 x 60 mm




A



1 x 1



2 x 2





4 x 5




1 x 6


B



1 x 1



1 x 4






4 x 5




1 x 6

C



D



SIKO KOUPELNY a.s.
Skorkovská 1310, 198 00 Praha 9
IČ: 26065801