






Instalační návod
Inštalacný návod
Mounting Instruction
Montageanleitung
Инструкция по установке



SIKOWI80, SIKOWI80KS, SIKOWI80MR,
SIKOWI90, SIKOWI90KS, SIKOWI90MR,
SIKOWI100, SIKOWI100KS, SIKOWI100MR,
SIKOWI110, SIKOWI110KS, SIKOWI110MR,
SIKOWI120, SIKOWI120KS, SIKOWI120MR,
SIKOWI140, SIKOWI140KS, SIKOWIPROFIL,
SIKOWIPROFILC, SIKOZAV2, SIKOZAV2C





SIKOWI80/80KS/80MR,
 SIKOWI90/90KS/90MR,
 SIKOWI100/100KS/100MR,
 SIKOWI110/110KS/110MR,
 SIKOWI120/120KS/120MR,
 SIKOWI140/140KS/140KS

SIKOWIPROFIL, SIKOWIPROFILC





SIKOZAV2, SIKOZAV2C



2 1X	3 1X	4 1X
5 3X	6 3X	7 1X
8 2X		




5 2X	9 2X
10 1X	11 1X
12 1X	13 1X



1

Max.=1200mm

	A(mm)
SIKOWI80	770~778
SIKOWI90	870~878
SIKOWI100	970~978
SIKOWI110	1070~1078
SIKOWI120	1170~1178
SIKOWI140	1370~1378



1a Vnitřní strana koutu







1b

Ø6 mm

1c


1d

6





2

Poznámka:
Vnitřní strana koutu - easy clean






e

8








4





Instalační návod
Inštalacný návod
Mounting Instruction
Montageanleitung
Инструкция по установке


SIKOWIROZKS
SIKOWIROZ
SIKOWIROZC
SIKOWIROZCKS




1

RH


LH




2a




2b




2c




2




2d





2e



2f



3



4

